P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 1

BELKIN

Bluetooth™ Wireless Desktop

Enjoy the freedom and convenience of wireless input

User Manual

F8T042ukB

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 2

TABLE OF CONTENTS

Introduction 2
Overview
- Product Features 3
- System Requirements 4
- Package Contents. 5
- Specifications 6
- Supported Profiles 8

Software Setup 10
Hardware Setup 15
Initial Configuration Wizard 19
Connecting the *Bluetooth* Desktop 22
Connecting the *Bluetooth* Keyboard 24
Connecting the *Bluetooth* Mouse 28
Uninstalling the Software. 32
FAQs 33
Battery and Safety Information 36
Information 38

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 2

INTRODUCTION

Congratulations and thank you for purchasing the *Bluetooth* Wireless Desktop from Belkin. This breakthrough technology makes it easier than ever to connect many of your computing and communications devices—without physical connections or cables. Please be sure to review this User Manual carefully, to ensure that you take advantage of all the features and capabilities of your new *Bluetooth* Wireless Desktop.

Please note: References made to the Bluetooth USB Adapter are to equipment included with your Bluetooth Wireless Desktop, part number F8T042-B. The Bluetooth USB Adapter lets you easily add Bluetooth capabilities to your USB computer.

OVERVIEW

Product Features

The *Bluetooth* Desktop is compliant with *Bluetooth* Standard version 1.1 and:

- Offers the convenience of the wireless *Bluetooth* interface
- Features comfortable, ergonomic design
- Works at distances of up to 10 meters (33 ft.)
- Installs and operates easily
- Includes *Bluetooth* USB Adapter that allows you to connect up to 7 *Bluetooth* devices at one time

the Keyboard:

- Offers 104-button support
- Includes 17 Internet, multimedia, and application keys

the Mouse:

- Delivers the accurate response of optical technology
- Navigates easily, using 4 buttons and the scroll wheel

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 4

The USB Adapter is compliant with *Bluetooth* Standard Version 1.1 and provides:

- Compliance with *Bluetooth* specification v1.1 devices
- USB bus powering; no external power supply necessary
- Support for Microsoft® Windows® 98SE, Me, 2000, XP and Server 2003.
- Operating distance of up to 10 meters
- Point-to-multipoint connections
- Support for data rates up to 721Kbps
- Built-in security, including up to 128-bit encryption and authentication
- Compatibility with USB desktop and notebook computers

System Requirements

- PC-compatible computer, CPU speed 200MHz or above
- Memory: 64MB or above, 128MB recommended
- One available USB port, USB 1.1 standard
- Windows® 98SE, Me, 2000, XP and Server 2003.

OVERVIEW

Package Contents

- *Bluetooth* Wireless Keyboard
- *Bluetooth* Wireless Optical Mouse
- *Bluetooth* USB Adapter
- USB base with 6 ft. extension
- CD-ROM for installation and documentation
- User Manual
- Quick Installation Guide
- Registration Card
- 6 AA Batteries

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 6

Wireless Specifications

Bluetooth Compliance	Version 1.1 Compatible to *Bluetooth* HID profile 0.95c
Operating Frequency	2.4 to 2.4835GHz
Output Power	Class II (<4 dBm) RF output power
Operation Range	10-meter (33 ft.) radius indoors
Antenna	Integrated

Mouse Specifications

Pointing Device	Optical, 800dpi
Buttons	4+ scroll-wheel button
Batteries Required	2 AA (included)
Battery Life	25 days under normal usage; 100 days standby

Specifications subject to change without notice.

OVERVIEW

Keyboard Specifications

Buttons/Keys	104+ 17 Multimedia/ Internet buttons
Batteries Required	4 AA (included)
Battery Life	25 days under normal usage; 100 days standby
USB Backup	USB “B”-Type Connector

General Specifications

Dimensions	
Mouse	74 (W) x 130 (L) x 45mm (H)
Keyboard	495 (W) x 196.9 (L) x 25.4mm (H)
Weight	
Mouse	108g (without battery)
Keyboard	308g (without battery)

Specifications subject to change without notice.

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 8

Supported Profiles

The services supported by your USB Adapter are defined as "Profiles".
Available profiles include:

Serial Port

Object Exchange

Personal Area Network

LAN Access

File Transfer

Human Interface Device*

Dial-Up Networking

Syncronization

Hardcopy Cable Replacement

Headset

Fax

Audio Gateway

**Supported by Bluetooth Keyboard and Mouse*

Your USB Adapter gives you the ability to do the following—without cables:

- Transfer files
- Access dial-up networks
- Connect to local area networks
- Perform an ActiveSync® session
- Connect to serial ports
- Print
- Exchange PIM data
- Send or exchange business cards
- Connect to input devices

The basic functions of the *Bluetooth* Neighbourhood include:

- Device Discovery
- Service Discovery
- Establishing links with remote devices

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 10

Installing the USB Adapter

Software Setup for Windows 98 SE, Me, 2000, and XP

To install the software for the USB Adapter, follow the instructions below:

The installation process for Windows XP may look slightly different from Windows 98 SE, Me, and 2000.

Note: Do not insert the USB Adapter into the USB port prior to installation.

1. Insert the software installation CD into the PC's CD-ROM drive.
2. The "Software InstallShield Wizard" window appears. Click on "Next" to begin the installation process.


Belkin Bluetooth Software 1.3.2.7 - InstallShield Wizard
Welcome to the InstallShield Wizard for Belkin Bluetooth Software 1.3.2.7
The InstallShield(R) Wizard will install Belkin Bluetooth Software on your computer. To continue, click Next.
WARNING: This program is protected by copyright law and international treaties.
< Back
Next >
Cancel

3. Choose "I accept the terms in the license agreement" to accept the license agreement. Click on "Next" to continue.
4. Specify the location where the software files will be installed on your hard drive. It is recommended that you install the software in the default directory "C:\Program Files\Belkin*Bluetooth*\Software\". Click on "Next" to continue.


Belkin Bluetooth Software 1.3.2.7 - InstallShield Wizard
License Agreement
Please read the following license agreement carefully.
WIDCOMM, INC. ("WIDCOMM") IS WILLING TO LICENSE THE WIDCOMM SOFTWARE ACCOMPANYING THIS LICENSE AGREEMENT (THE "SOFTWARE") TO YOU ONLY ON THE CONDITION THAT YOU ACCEPT ALL OF THE TERMS IN THIS AGREEMENT. PLEASE READ THE TERMS CAREFULLY. BY CLICKING ON THE "I ACCEPT THE TERMS OF THIS LICENSE AGREEMENT" BUTTON YOU ACKNOWLEDGE THAT YOU HAVE READ THIS AGREEMENT, UNDERSTAND IT AND AGREE TO BE
I accept the terms in the license agreement
I do not accept the terms in the license agreement
InstallShield
< Back
Next >
Cancel


Belkin Bluetooth Software 1.3.2.7 - InstallShield Wizard
Destination Folder
Click Next to install to this folder, or click Change to install to a different folder.
Install Belkin Bluetooth Software 1.3.2.7 to:
C:\Program Files\Belkin\Bluetooth Software\
Change...
InstallShield
< Back
Next >
Cancel

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 12

5. Confirm that the device software is ready to be installed and click on "Install".

6. The InstallShield Wizard will begin to install the *Bluetooth* software. This may take several minutes.


Belkin Bluetooth Software 1.3.2.7 - InstallShield Wizard
Ready to Install the Program
The wizard is ready to begin installation.
Click Install to begin the installation.
If you want to review or change any of your installation settings, click Back. Click Cancel to exit the wizard.
InstallShield
< Back
Install
Cancel


Belkin Bluetooth Software 1.3.2.7 - InstallShield Wizard
Installing Belkin Bluetooth Software
The program features you selected are being installed.
Please wait while the InstallShield Wizard installs Belkin Bluetooth Software. This may take several minutes.
Status:
InstallShield
< Back
Next >
Cancel

7. During the installation process, you will be prompted to insert your *Bluetooth* USB Adapter. If your Adapter is not plugged into your computer at this time, you may insert it into an available USB 1.1-compliant port on your desktop or notebook, then click "OK" to continue. Refer to the "Hardware Setup" section on page 15 for detailed instructions on connecting the USB Adapter to your computer.


Bluetooth device not found
No Bluetooth device was detected. Please make sure that your Bluetooth device is plugged in properly and click 'OK' to continue installation. Click 'Cancel' to continue installation without the Bluetooth device.
OK
Cancel

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 14

Note: If at any time during the installation process you receive a "Driver Signature Notice", click "OK" to continue the installation process.

8. Confirm the completion of the software installation; click "Finish" and restart the system if prompted to do so.


Belkin Bluetooth Software 1.3.2.7 - InstallShield Wizard
Installing Belkin Bluetooth Software
Driver Signature Notice
Currently Microsoft does not have a certification program in place for Bluetooth devices. As a result, at this time it is not possible to provide certified drivers for Bluetooth devices. In the event that Microsoft implements a Windows Logo certification process for Bluetooth devices, signed drivers will be made available.
To avoid receiving several prompts for signed drivers during the installation process, select OK to disable unsigned driver warnings, and proceed with the installation. The default warning option will be re-enabled at the completion of the installation of the Bluetooth drivers. This option is an effort to provide the best customer experience while using this product. If you select Cancel, the installation will continue without disabling the warnings and you will be required to select Continue at each prompt to proceed with the installation.
OK
Cancel
InstallShield
< Back
Next >


Belkin Bluetooth Software - InstallShield Wizard
InstallShield Wizard Completed
The InstallShield Wizard has successfully installed Belkin Bluetooth Software. Click Finish to exit the wizard.
< Back
Finish
Cancel

USB Adapter

You must connect the *Bluetooth* USB Adapter to an available Universal Serial Bus (USB) port on your computer.

Note: Your USB Adapter is sensitive to static electricity, which can damage its delicate electrical components. Electrostatic charges can be acquired simply by dry weather conditions or they can occur when you walk across carpeted floors. To protect your device, always touch the metal chassis of your computer before handling the USB Adapter, or any internal computer component. This will ground a potential electrostatic discharge. Avoid touching the metal connector when handling the USB Adapter.

There are two ways to connect your USB Adapter:

1. Connect the USB Adapter directly to an available USB A-type connector on your desktop or notebook computer.

2. Connect the USB Adapter to the included USB base stand, and then connect the other end of the cable to an available USB A-type connector on your desktop or notebook computer. This is recommended for desktop computers.

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 16

Hardware Setup for Windows 98 SE, Me, 2000, and XP

1. Once you have connected the USB Adapter, your system will display a "New USB device found". Follow the prompts to install drivers for your Adapter.
2. Choose "Install from a list or Specific location"; then click "Next".

Found New Hardware Wizard
Welcome to the Found New Hardware Wizard
This wizard helps you install software for:
CSR USB Bluetooth Device
If your hardware came with an installation CD or floppy disk, insert it now.
What do you want the wizard to do?
Install the software automatically (Recommended)
Install from a list or specific location (Advanced)
Click Next to continue.
< Back
Next >
Cancel

3. Browse for the location of the device driver "C:\Program Files\Belkin\ *Bluetooth*\Software\bin\" then click "Next".
4. If you receive the following "Hardware installation notice", click on "Continue Anyway" to continue with the installation process.


Found New Hardware Wizard
Please choose your search and installation options.
Search for the best driver in these locations.
Use the check boxes below to limit or expand the default search, which includes local paths and removable media. The best driver found will be installed.
Search removable media (floppy, CD-ROM...)
Include this location in the search:
C:\Program Files\Belkin\Bluetooth Software\bin
Browse
Don't search. I will choose the driver to install.
Choose this option to select the device driver from a list. Windows does not guarantee that the driver you choose will be the best match for your hardware.
< Back
Next >
Cancel

Hardware Installation
The software you are installing for this hardware:
USB Bluetooth Device
has not passed Windows Logo testing to verify its compatibility with Windows XP. (Tell me why this testing is important.)
Continuing your installation of this software may impair or destabilize the correct operation of your system either immediately or in the future. Microsoft strongly recommends that you stop this installation now and contact the hardware vendor for software that has passed Windows Logo testing.
Continue Anyway
STOP Installation

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 18

5. A window will appear that confirms the completion of the hardware installation; click on "Finish" to complete the installation process.



Configuring your Computer for Windows 98 SE, Me, 2000, and XP

1. Once the installation process is complete, the "Initial *Bluetooth* Configuration Wizard" will prompt you. Follow the prompts as the Wizard guides you through the initial setup of your *Bluetooth* device.

2. Name your computer with a name you can easily remember. This name will appear in reference to your computer when it is discovered by other *Bluetooth* devices.

Initial Bluetooth Configuration Wizard
Initial Bluetooth Configuration Wizard
Before you can begin using Bluetooth on this computer you must perform some initial setup. This wizard will help you to configure a basic Bluetooth environment.
You can access the Bluetooth features on this computer through the Bluetooth icon on the desktop or in the system tray. This icon can also appear in the following locations. Select the locations you want the icon to appear and click Next.
Add the icon to the Start menu
Add the icon to the Programs menu
Add the icon to My Computer
< Back
Next >
Cancel

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 20

3. Choose the type of computer you have installed the *Bluetooth* USB Adapter to in the drop-down menu and click "Next".

4. Continue to use the Wizard to configure the *Bluetooth* services that this computer will allow other *Bluetooth* devices to access. Click "Next".


General
Device Name and Type:
You must select a name for this computer and indicate what type of computer it is.
Belkin Bluetooth Software 1.3.2.7
Identity
Enter a unique name for this computer. This name will be displayed to other Bluetooth devices if this computer is configured to allow itself to be discovered.
Select a computer type from the drop-down menu. This selection determines the icon that represents this computer on remote devices.
Computer name: My Laptop
Computer type: Laptop
< Back
Next >
Cancel


Initial Bluetooth Configuration Wizard
Initial Bluetooth Configuration Wizard
To configure the Bluetooth services that this computer will make available for other Bluetooth devices to use, click Next.
If you do not want to change the configuration for this computer's Bluetooth services or if you prefer to change the configuration later, click Skip.
Skip
< Back
Next >
Cancel

5. Choose the *Bluetooth* services your computer will offer. The most common service for your computer type will be checked by default.

Congratulations! Your computer is ready to connect to your *Bluetooth* devices. If you have another *Bluetooth* device and you want to configure the way this computer will use its services, click "Next". Otherwise click "Skip", and proceed to the "Connecting the *Bluetooth* Desktop" section of this manual on page 22.


Bluetooth Service Selection
Choose the services that this computer will offer:
To enable a service, place a check in the box next to the service name.
To display the properties panel for a service, click Configure.
PIM Item Transfer
Allow remote Bluetooth devices to exchange business cards with this computer. Accept Personal Information Manager (PIM) items such as calendar items, contacts, notes and messages from remote Bluetooth devices.
Configure
PIM Synchronization
File Transfer
Network Access
Dial-up Networking
Bluetooth Serial Port
< Back
Next >
Cancel


Initial Bluetooth Configuration Wizard
Initial Bluetooth Configuration Wizard
If you have another Bluetooth device and you want to configure the way this computer will use its services, click Next. Otherwise click Skip.
Skip
< Back
Next >
Cancel

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 22

The following steps will allow you to establish the initial connection between your Wireless Desktop and computer. Once a connection is established, your computer will automatically connect every time to boot your computer. If for any reason the Desktop does not reconnect at boot-up, follow the pairing and connection procedures on page 24.

Note: You must have a functional keyboard other than the Bluetooth Keyboard connected to your computer to complete the hardware installation. Please do not remove any attached keyboards until you have confirmed that your Bluetooth Keyboard is operational.

CONNECTING THE *BLUETOOTH* DESKTOP

Inserting the Batteries

The Keyboard requires four AA batteries and the Mouse requires two AA batteries to run (included). When it becomes necessary to replace them, be sure to use new batteries only; we recommend alkaline batteries. Rechargeable batteries may be used as well.

To insert the batteries:

1. Turn the Keyboard and Mouse upside down, and remove the battery compartment cover.
2. Insert the new batteries. Make sure to properly orient the positive (+) and negative (-) ends as indicated on the battery compartment label.
3. Close the battery compartment cover.

Important: Before boarding any aircraft, remove the batteries from the Wireless Desktop. The Desktop can transmit radio frequency energy, much like cellular phones, whenever the batteries are installed.

Please refer to the “Battery and Safety Information” section on page 36 for more information regarding the handling and usage of batteries.

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 24

Preparing the Keyboard

1. Turn the Keyboard upside down, and press the "Connect" button once. You should see the LED blink rapidly. This indicates that the Keyboard is in pairing mode and is ready to connect to your computer.



2. On your computer, open "My *Bluetooth* Places" by double-clicking on the *Bluetooth* icon.

3. From the menu bar, select "*Bluetooth*" then "*Bluetooth* Setup Wizard".

4. Select "I know the service I want to use and I want to find a *Bluetooth* device that provides that service." Then click "Next".




Bluetooth Setup
Welcome to the Bluetooth Setup Wizard
This Wizard will help you set up your Bluetooth environment.
What would you like to do?
I know the service I want to use and I want to find a Bluetooth device that provides that service.
I want to find a specific Bluetooth device and configure how this computer will use its services.
I want to configure the Bluetooth services that this computer will provide to remote devices.
I want to change the name and/or device type that this computer displays to other Bluetooth devices.
< Back
Next >
Cancel

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 26

5. From the menu, scroll down to select “Human Interface Device” then click on “Next”. Please verify that the LED continues to flash rapidly.

6. The *Bluetooth* Keyboard will be discovered. Click on the *Bluetooth* Keyboard icon then click “Next”.


Bluetooth Service Selection
Services provided by remote devices
The services listed below may be provided by nearby Bluetooth devices. Select a service from the list to see a description of that service. Click Next to search for devices that offer the selected service.
Click a service to select it.
File Transfer
Fax
PIM Synchronization
Headset
Audio Gateway
Printer
Human Interface Device.
Use a Bluetooth enabled mouse, keyboard or other interface device.
< Back
Next >
Cancel


Bluetooth Device Selection
Select a device
Remote devices must be in Discoverable mode for this computer to find them. For assistance in making a remote device discoverable, refer to the remote device's documentation.
BELKIN Keyboard
Search Again
Show mice, keyboards and joysticks
If device you are looking for is not in the list, verify that the device has power and is operational. Some devices require to press a special button to be Discoverable.
< Back
Next >
Cancel

7. The “Pairing Procedure” window will appear. Click on the “Initiate Pairing” button on the screen.

8. On your *Bluetooth* Keyboard, type the unique pin-code digits and press the “Enter” key.

9. Type the name you would like your Keyboard to appear as and click “Finish”.

Your Keyboard is now connected. Type with your Keyboard to verify the connection.


Bluetooth Security Setup
Bluetooth Pairing Procedure
The Pairing Procedure generates a secret key that will be used for authentication and encryption in future connections to this device.
For a brief description of pairing, click Pairing Help. For more detailed information, consult your user's manual.
Pairing Help
Click the Initiate Pairing button on the screen. On your Bluetooth keyboard type the following digits and press the Enter key.
Initiate Pairing
PIN Code: 7411558
Initiate Pairing
< Back
Next >
Cancel

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 28

The following steps will allow you to establish the initial connection between your Mouse and computer. Once a connection is established, your computer will automatically connect to your Mouse every time you reboot. If the Mouse does not reconnect at boot-up, follow the pairing and connection procedures on page 24.

Preparing the Mouse

1. Turn the Mouse upside down, and press the "Connect" button once. You should see the Scroll Wheel LED blink rapidly. This indicates that the Mouse is in pairing mode and is ready to connect to your computer.
2. On your computer, open "My *Bluetooth* Places" by double-clicking on the *Bluetooth* icon.



CONNECTING THE *BLUETOOTH* MOUSE

3. From the menu bar select "*Bluetooth*" then "*Bluetooth* Setup Wizard".
4. Select "I want to find a specific *Bluetooth* device and configure how this computer will use its services". Then click "Next".




Bluetooth Setup
Welcome to the Bluetooth Setup Wizard
This Wizard will help you set up your Bluetooth environment.
What would you like to do?
I know the service I want to use and I want to find a Bluetooth device that provides that service.
I want to find a specific Bluetooth device and configure how this computer will use its services.
I want to configure the Bluetooth services that this computer will provide to remote devices.
I want to change the name and/or device type that this computer displays to other Bluetooth devices.
< Back
Next >
Cancel

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 30

5. From the drop-down menu, select "Show mice, keyboards and joysticks" then click on the "Search Again" button. Please verify that the Scroll Wheel LED continues to flash rapidly.
6. The Belkin Mouse will be discovered. Click on the Belkin Mouse icon then click "Next".


Belkin Bluetooth Software 1.3.2.7 - InstallShield Wizard
Welcome to the InstallShield Wizard for Belkin Bluetooth Software 1.3.2.7
The InstallShield(R) Wizard will install Belkin Bluetooth Software on your computer. To continue, click Next.
WARNING: This program is protected by copyright law and international treaties.
< Back
Next >
Cancel


Bluetooth Device Selection
Select a device
Remote devices must be in Discoverable mode for this computer to find them. For assistance in making a remote device discoverable, refer to the remote device's documentation.
BELKIN MOUSE
Search Again
Show mice, keyboards and joysticks
If device you are looking for is not in the list, verify that the device has power and is operational. Some devices require to press a special button to be Discoverable.
< Back
Next >
Cancel

7. The services that are available from the device will be listed. Select "*Bluetooth* Mouse" and click "Finish".
8. Wait while the Mouse is installed. This may take several seconds.
9. Your Mouse is now connected. Move your Mouse to verify the connection.


Bluetooth Service Selection
Select the services you are interested in.
The following services are available through the selected Bluetooth Device.
Select the service that you want to access on the selected device.
Bluetooth Mouse
Use a Bluetooth enabled mouse, keyboard or other interface device.
Refresh
< Back
Finish
Cancel

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 32

UNINSTALLING THE SOFTWARE

Uninstalling the Software for Windows 98 SE, Me, 2000, and XP

Follow these instructions to uninstall your *Bluetooth* USB Adapter.

1. Insert the CD-ROM included with your USB Adapter.
2. The "InstallShield Wizard" should automatically load. If it does not load, explore the CD and run the "Setup.exe" file.
3. The "InstallShield" window should now appear. Click "Next" to continue with the uninstall process.

FAQs

Which *Bluetooth* Profiles does the USB Adapter support?

The included *Bluetooth* USB Adapter supports the most current *Bluetooth* profile set including: Service Discovery, File Transfer, LAN Access, Serial Port, DUN, Generic Object Exchange, Business Card, Push, Pull & Exchange, Fax, Synchronisation, PAN, HCRP, Audio Gateway, Headset, and Human Interface Device.

Which Bluetooth Profiles does the *Bluetooth* Wireless Desktop (the Desktop) Support?

The Desktop supports the Human Interface Device profile.

Will the Desktop reconnect after I restart the computer?

Yes, the Desktop will automatically establish a connection with your PC every time Windows restarts.

Will my *Bluetooth* Keyboard work prior to Windows loading?

At this time, the *Bluetooth* Keyboard will only operate inside the Windows environment. You must use a keyboard that is connected directly to your computer to access your system BIOS. Future firmware upgrades for the *Bluetooth* USB Adapter that is included with this product will allow your *Bluetooth* Keyboard to function prior to Windows booting.

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 34

What does the scroll wheel LED indicate?

- A slow blink every three seconds indicates normal operation.
- A rapid blink indicates that the mouse is in connection mode and is ready to be discovered and connected.
- Intermittent rapid blinking (every three seconds) indicates the battery is low.

What does the keyboard LED indicate?

- Blinks once every second – Keyboard in Discoverable mode.
- Blinks every four seconds – Normal operation mode.
- Constantly on – Replace batteries

Can I connect multiple *Bluetooth* Keyboards and Mice to the same computer?

Yes, you may. *Bluetooth* can support up to seven simultaneous connections. Simply follow the pairing and connection instructions in this User Manual to add *Bluetooth* Keyboard or Mouse connections to your computer.

Can I use rechargeable AA batteries with the Desktop?

Yes, you may.

Can my Desktop connect to other *Bluetooth* devices or adapters?

Yes, it can, as long as the other *Bluetooth* device supports the Human Interface Device (HID) profile. Check with the device manufacturer to see if your device supports HID Profiles. For WIDCOMM software users, you must have BTW version 1.4 or higher.

Can my Microsoft *Bluetooth* Keyboard and Mouse connect to my Belkin *Bluetooth* USB Adapter included with this package?

Yes, it can. Follow the Keyboard and Mouse connection procedure as described above in this User Manual.

Can I connect the Belkin *Bluetooth* Keyboard and the Microsoft *Bluetooth* Keyboard to the same computer at the same time?

Yes, you can.

P74374uk_F8T042-B_man.qxd 4/22/04 10:08 AM Page 36

General Precautions

Keep batteries out of reach of children.

Do not mix old and new batteries or batteries of different types (for example, carbon and alkaline batteries).

Always remove old, weak, or worn-out batteries promptly and recycle or dispose of them in accordance with local and national disposal regulations.

If a battery leaks, remove all batteries and recycle or dispose of them in accordance with the battery manufacturer's instructions and local and national disposal regulations. Before inserting new batteries, thoroughly clean the battery compartment with a damp paper towel, or follow the battery manufacturer's recommendations for cleanup. If fluid from the battery comes into contact with skin or clothes, flush skin with water immediately.

Remove the batteries if your device is to be stored for longer than a month without being used.

BATTERY AND SAFETY INFORMATION

Special Precautions

The precautions below are to prevent the sudden release of electrolytes, which these prohibited actions can cause:

Do not open, puncture, or mutilate the batteries.

Do not heat batteries.

Do not use a fire to dispose of batteries.

Released battery electrolyte is corrosive, can cause damage to the eyes and skin, and may be toxic if swallowed.

Product Disposal Information

Dispose of this product in accordance with local and national disposal regulations.

P74374uk_F8T042-B_man.qxd 4/22/04 10:09 AM Page 38

DECLARATION OF CONFORMITY WITH FCC RULES FOR ELECTROMAGNETIC COMPATIBILITY

We, Belkin Corporation, of 501 West Walnut Street, Compton, CA 90220, declare under our sole responsibility that the products,

F8T040, F8T041, F8T005

to which this declaration relates, comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Exposure to Radio Frequency Radiation.

The radiated output power of this device is far below the FCC radio frequency exposure limits. Nevertheless, the device shall be used in such manner that the potential for human contact normal operation is minimised.

When connecting an external antenna to the device, the antenna shall be placed in such a manner to minimise the potential for human contact during normal operation. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, human proximity to the antenna shall not be less than 20cm (8 inches) during normal operation.

Federal Communications Commission Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy. If not installed and used in accordance with the instructions, it may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Modifications

The FCC requires the user to be notified that any changes or modifications to this device that are not expressly approved by Belkin Corporation may void the users authority to operate the equipment.

Canada-Industry Canada (IC)

The wireless radio of this device complies with RSS 139 & RSS 210 Industry Canada. This Class B digital complies with Canadian ICES-003.

Cet appareil numérique de la classe B conforme á la norme NMB-003 du Canada.

Europe-European Union Notice

Radio products with the CE alert marking comply with the R&TTE Directive (1995/5/EC) issued by the Commission of the European Community.

P74374uk_F8T042-B_man.qxd 4/22/04 10:09 AM Page 40

Compliance with this directive implies conformity to the following European Norms (in brackets are the equivalent international standards).

- EN 60950 (IEC60950) – Product Safety
- EN 300 328 Technical requirement for radio equipment
- ETS 300 826 General EMC requirements for radio equipment.

To determine the type of transmitter, check the identification label on your Belkin product.

Products with the CE marking comply with the EMC Directive (89/336/EEC) and the Low Voltage Directive (72/23/EEC) issued by the Commission of the European Community. Compliance with these directives implies conformity to the following European Norms (in brackets are the equivalent international standards).

- EN 55022 (CISPR 22) – Electromagnetic Interference
- EN 55024 (IEC61000-4-2,3,4,5,6,8,11)- Electromagnetic Immunity
- EN 61000-3-2 (IEC610000-3-2) - Power Line Harmonics
- EN 61000-3-3 (IEC610000) – Power Line Flicker
- EN 60950 (IEC60950) – Product Safety

Products that contain the radio transmitter are labelled with the CE alert marking and may also carry the CE logo.

INFORMATION

Belkin Corporation Limited Two-Year Product Warranty

Belkin Corporation warrants this product against defects in materials and workmanship for its warranty period. If a defect is discovered, Belkin will, at its option, repair or replace the product at no charge provided it is returned during the warranty period, with transportation charges prepaid, to the authorised Belkin dealer from whom you purchased the product. Proof of purchase may be required.

This warranty does not apply if the product has been damaged by accident, abuse, misuse, or misapplication; if the product has been modified without the written permission of Belkin; or if any Belkin serial number has been removed or defaced.

THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE IN LIEU OF ALL OTHERS, WHETHER ORAL OR WRITTEN, EXPRESSED OR IMPLIED. BELKIN SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

No Belkin dealer, agent, or employee is authorised to make any modification, extension, or addition to this warranty.

BELKIN IS NOT RESPONSIBLE FOR SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY, OR UNDER ANY OTHER LEGAL THEORY, INCLUDING BUT NOT LIMITED TO, LOST PROFITS, DOWNTIME, GOODWILL, DAMAGE TO OR REPROGRAMMING OR REPRODUCING ANY PROGRAM OR DATA STORED IN, OR USED WITH, BELKIN PRODUCTS.

Some states do not allow the exclusion or limitation of incidental or consequential damages or exclusions of implied warranties, so the above limitations of exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

P74374uk_F8T042-B_man.qxd 4/22/04 10:09 AM Page 42

BELKIN

belkin.com

Belkin Corporation
5501 West Walnut Street
Compton • CA • 90220-5221 • USA
Tel: +1 310 898 1100
Fax: +1 310 898 1111

Belkin Ltd.
Express Business Park • Shipton Way
Rushden • NN10 6GL • United Kingdom
Tel: +44 (0) 1933 35 2000
Fax: +44 (0) 1933 31 2000

Belkin B.V.
Boeing Avenue 333
1119 PH Schiphol-Rijk • The Netherlands
Tel: +31 (0) 20 654 7300
Fax: +31 (0) 20 654 7349

Belkin GmbH
Hanebergstrasse 2
80637 München • Germany
Tel: +49 (0) 89 143405 0
Fax: +49 (0) 89 143405 100

Belkin Components SAS
5 Rue du Petit Robinson • 3ème étage
78350 Jouy en Josas • France
Tel: +33 (0) 1 34 58 14 00
Fax: +33 (0) 1 39 46 62 89

Belkin Ltd
7 Bowen Cresent • West Gosford
NSW 2250 • Australia
Tel: +61 (0) 2 4372 8600
Fax: +61 (0) 2 4372 8603

Belkin Tech Support
Europe: 00 800 223 55 460
US: 877 736 5771

P74374uk

© 2003 Belkin Corporation. All rights reserved. All trade names are registered trademarks of respective manufacturers listed.
The *Bluetooth* name and the *Bluetooth* trademarks are owned by *Bluetooth* SIG, Inc., and are used by Belkin Corporation under license.
Mac OS is a trademark of Apple Computer, Inc. registered in the U. S. and other countries.